

Zhejiang Aoma Elevator Co.,Ltd

TTD ZHEJIANG AON USEFUJI TIDILAT Stair elevator

Let the elderly at home easily go up and down the stairs

Zhejiang Aoma Elevator Co.,Ltd

Add:No.2555, Qianghua Road, Nanxun Economic Development Zone,

Tel:+86-0572-3636576



н. evator

Intellectual straight-rail stair chair lift

www.vksfujilift.com

Stair chair lift can help the old / disabled to independently up / down the stairs. It solves the problem of difficult up / down with convenient installation. It operates along the rail left / right of the stairs. It does not destroy any family facilities. It is especially suitable for decorated houses. Stair chair lift applies combination of steel structure, aluminum alloy casting and combustible plastic housing with safe and reliable properties, popular and attractive outline.

Intellectual auxiliary hoist intellectual hoist electric balancing device

Excellent design of intellectual hoist Ai system ensures that operator is in the correct ergonomics position. Meanwhile, it can fully control the load. Control handle is equipped with programming software. It can be tailor-made according to the clients' application requirements. Linear instinct induced handle controls the intellectual hoist servo system. Therefore it can train less operators. Handle is reacted by instant touch. Hold and operate it to move the load.

EVALUATE Stelling Aoma Elevator Co.,Ltd





M

Curved Stair Lift

- A new design concept from the UK
- ZHEJIANG AOMA The latest control technology in the whole industry
- Double-tube steel rail, track angle 0-52 degrees
- Armrests, leather cushions, and footrests are fordable design
- ✤ All new swivel seat design
- Ergonomic control lever design
- Electronic self-locking seat belt
- Seven-layer safety protection system for the whole machine ZHEJIANG A
- LCD status and diagnostic display
- Sensitive safety sensor
- Over-speed safety protection system
- Intelligent call service system
- Built-in battery management system
- Set up multiple charging piles
- Electric foot pedal optional
- Maximum load of standard model 120KG
- The maximum load of the heavier model is 160KG

OR

UIAL

Double track curved stairlift

Switch control paddle



Sensitive safety

sensing device



Folding foot pedal

• Swivel seat





Diagnosis display screen

ZHEJIANG A Electronic self-locking seat belt

Double-tube Steel rail

03

Picture of leather linear stair lift










Overspeed safety protection system




During the operation of the Aoma stairlift, if the running speed exceeds the safe speed set by the system, the whole machine will immediately cut off the power supply to stop running and mechanically brake to ensure absolute safety. In this case, please contact our after-sales service engineer to check and repair for you Maintain it to return to normal use.

Aoma stairlift remote control system. In the case of inching function, colleagues have also added linkage function. Users can freely choose according to their needs. The remote control can control the stairlift to move up or down automatically. The operation is simple and convenient.

Intelligent call service system







Before installation, the stairlift was surveyed by a professional engineer and measured with a 3D photogrammetric system. The dimensions were accurate.



Aoma stairlift are carefully designed and tailored according to the data of the 3D photogrammetric system. Each customer has a unique design plan. After the plan makes the customer satisfied, the production will start.



Measurement methods



LED status and diagnostic display





IARGING

The LCD display screen displays the running status and fault code of the stairlift in real time. If you encounter a problem during operation, you can refer to the user manual for diagnosis and solution based on the code on the LCD display.

Common problems can be diagnosed by themselves and normal operation can be resumed. There no need to contact an after-sales service engineer.







Leather seat back cushion standard color



Blue



Deep blue

A variety of seat back cushion styles and colors are available. If you have special requirements, we can customize it according to your preferences and needs.

Red

Beige

PU seat back cushion standard color

Oriental Red

Telecom Gray

Main parameter table of Aoma stair elevator

Product name	Leather curved stair lift	PU Curved Stair Elevator	Leather linear seat elevator	Transfer method	Rack and pinion (Add lubricating grease)
Product model	Aoma-C88	Aoma-C89	Aoma-S188	Drivar	
Product picture			EATOR	Driver Motor Power Use Voltage/Current	DC motor drive 350W 24V / 0-18A
Charging mathed	Automatic charging at both ends of the track, which	Automatic charging at both ends of the track, which can	Automatic charging at both	Charging Voltage/Current	100-240v/ 1.2A
Charging method	can increase the middle charging position	increase the middle charging position	ends of the track	Energy consumption	About 0.014kwh
Foot pedal	Manual (standard) Electric (optional)	Manual (standard) Electric (optional)	Manual (standard)	Battery	12V9Ah *2 (Lead-acid batteries)
Seat back cushion	PVC fabric, three colors are available	PU process, three colors are available	PVC fabric, three colors are available	Speed	0.12m/s
Track material	Φ 38 $ imes$ T3mm Steel pipe	Φ 38 $ imes$ T3mm Steel pipe	High-strength aluminum alloy	Armrest LCD display	Display running status
Track surface treatment	Electrostatic spraying, two colors are available	Electrostatic spraying, two colors are available	Silver matte anodized		and fault code
Orbit angle	0° -52°	0° -52°	25° -55°	Seat Rack tooth width	Rotatable seat
Standard maximum load	120KG	120KG	120KG	Way over the line	Threading inside the track
Maximum load for heavier models	160KG	160KG	140KG	Fixed way	Screw fixed to the ground



Hydraulic stair wheelchair lift

The barrier-free lift is a lift specially designed and manufactured for the disabled. In order to facilitate the travel and sightseeing of the disabled, in communities, hospitals, schools, hotels, hotels, public places and other places. Barrier-free elevators are installed next to the escalator in the tourist elevator passage. The barrier-free lift can accommodate wheelchairs and vehicles. The disabled or people with limited mobility only need to press the help buttons at both ends, and the staff on duty will immediately turn on the automatic lift.

✤ It is a small hydraulic elevator that replaces elevators. It uses the remaining space in the corner to install on the wall, which is convenient and quick, does not occupy the area of the room, and is economical and suitable for replacing the elevator. It is suitable for two- and three-story buildings, leap-type buildings, attics, basements and other small areas. It saves the floor space of the stairs, increases the room space, uses less electricity, and has low noise. It is an ideal new product to replace the stairs. 220v voltage input and 36v low voltage output to ensure the safety of electricity use. Buttons can be installed in layers to achieve multi-point control. There are tracks and pits for customers to choose. Specifications can be flexibly designed according to the actual situation on site.

Oblique hanging type barrier-free / Vertical barrier-free seat lifting platform



High safety factor
 Full travel anti-fall system
 Power failure protection, lock immediately after power failure

Fully automatic folding system
 No need for human intervention during any deformation operation
 MC
 Hammer drive mode

Hammer drive mode
 Can be adapted to any arc installation scene

Simple and convenient operation
 Humanized operation and comfortable ride

Energy saving and environmental protection
 Low energy consumption during use, low maintenance cost

• Anti-collision function The guardrail can automatically monitor the displacement and operate the exhibition hall equipment to ensure the safety of passengers

Built-in battery
 Ensure that the equipment can be folded without external power

Emergency button
 The device brakes immediately after pressing the emergency stop
 button in the running state

Equipped with electromagnetic lock
 The guardrail door is equipped with an electromagnetic lock, and the door can be opened after reaching a safe position

More pictures



OR CO., LTD ZHEJIANG AOMA ELEVATOR CO., LTD ZHEJIANG AOM (REFUJI

JATOR CO., LTD ZHEJ ANG



+86-0572-3636576



cyma@vksfujilift.com